

**PLEASE FOLLOW THESE INSTRUCTIONS TO
UPDATE THE POSTAGE RATES IN YOUR SCALE**

PLEASE DO NOT LOAD UNTIL MONDAY 26th MARCH 2018



Model: DI PIP 5, 10 & 30kg external weighing platform



STEP 1

Turn the power 'OFF' at the wall socket
Failure to not switch off may damage your scales



STEP 2

Turn keyboard over and remove the old rate chip



STEP 3

Take the new chip out of the packaging



STEP 4

Insert the new chip with the yellow dot facing the adjacent yellow marking on the keyboard, press in firmly



STEP 5

Turn the keyboard back over then turn the power back 'ON'